



## NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS

|           | ОТН      | HERWISE SHOWN.                                    |
|-----------|----------|---|
| REVISI    | ONS      | ILLINOIS DEPARTMENT OF TRANSPORTATION             |
| NAME      | DATE     |   |
| R. SHAH   | 10/25/94 | PAVEMENT PATCHING FOR<br>HMA SURFACED<br>PAVEMENT |
| R. SHAH   | 01/14/95 |   |
| R. SHAH   | 03/23/95 |   |
| R. SHAH   | 04/24/95 |   |
| A. HOUSEH | 03/15/96 |   |
| A. ABBAS  | 03/21/97 |   |
| A. ARRAS  | 01/20/98 |   |

PLOT DATE = 10/25/2007 FILE NAME = Widiststd/bd22.dgn FOT SCARE = 52.941 / IN. INSER NAME = hankel

04/27/98 01/01/07 09/04/01 SCALE; VERT. NONE DRAWN BY CHECKED BY BD400-04 (BD